

Polypropylene Wax Melter



IMPORTANT!

Read this user's manual before use and follow the given instructions.

Producer cannot be held responsible for any damages caused by improper use.



Electrics – Safety Issues

1. The device must be plugged into the grounded socket with a voltage specified on the rating label.
2. Electricity supply must be fitted with a residual current device with a rated tripping current not exceeding 30mA. The operation of the over-current protection needs to be checked periodically.
3. Check the condition of the cord periodically.
4. If the supply cord is damaged and needs to be replaced, this function should be performed at the guarantor or by special service or by a qualified person in order to avoid danger. Do not use the device if power cord is damaged. (applies to steam generator).
5. This device is not designed to be used by persons (including children) with limited physical, sensual or psychological abilities or persons who do not have experience or knowledge of the device unless it is done under supervision and according to the user manual passed by persons responsible for their safety. Keep away from children!
6. In case of damage, in order to avoid hazard, repairs can only be carried out by a special service or a qualified person.



Safety

- a) This device has been designed to acquire wax from drought by steam method.
- b) Place on dry surfaces only!
- c) Close the lid prior to commencing any work.
- d) Do not move or adjust the decrystalyzer whilst in use.
- e) Do not perform any maintenance whilst in use.
- f) Should any hazard arise, unplug the device immediately.
- g) Once danger has been eliminated, the device can be restarted
- h) Do not use the unit near flammable materials
- i) Do not power up without any drought to be melted.
- j) For indoor use only! Not to be used outdoors!
- k) Protect your controller against moisture (also while storing)



CAUTION!

Pulling the cord is strictly forbidden. Keep the cord away from sources of heat, sharp edges and ensure it is in good condition

MAINTENANCE

IMPORTANT!

Unplug the device before performing any maintenance!

Wash the device with hot water and small amount of detergent (food contact certified).

Rinse thoroughly with clean water after washing and leave until it is dry.

Store the device in a dry place.

Do not perform any maintenance of any elements by the use of chemicals.


This device has been designed to acquire wax from frames or drought itself by using a steam method.

• The kit includes:

1. PP container– capacity 33l.
2. Drought container – capacity 20l.
3. Metal stand
4. Wax tray
5. Steam generator:
 - power supply – 230V/50Hz
 - power – 1800W
 - capacity – 4l.

How to use:

1. Fill the steam generator with water up to max. level.
Plug the device in.
2. Fill the basket with drought material.
3. Close the lid tightly.
4. Wait until enough steam is generated and melted wax pours out.
5. Pay extra care not to get burnt by hot steam.
6. Once filling has been melted, check the water level and refill if necessary.
7. Should you run out of water inside the steam generator during melting, proceed as follows:
unplug the device
 - wait a while until the device cools down
 - turn valve **a)**
 - refill the steam generator with water.
 - close the valve
 - re-plug the device



8. Refill the basket with drought material.
9. Repeat steps 5 & 7 until melting has finished.
10. Once completed, unplug the device.
11. Clean the basket from all debris and make it ready for next use.