

Instructions Manual

STEAM GENERATOR



LYSON

Przedsiębiorstwo Pszczelarskie Łyson

Spółka z o.o.

34-124 Klecza Górna, st.Pszczela 2, Poland

www.lyson.eu, e-mail; lyson@lyson.com.pl

Tel. +48 33/875-99-40, +48 33/870-64-02

**The following manual encompasses the
device bearing the following code:**

2059

Table of contents

1. General safety rules
 - 1.1. Electrical safety
 - 1.2. Operation safety
2. Product description
 - 2.1. Preparation for use
 - 2.2. Technical specifications
3. Storage
4. Maintenance and Cleaning
5. Waste disposal and environmental protection
6. Warranty

Steam generator

Before first use read the manual carefully and follow the instructions contained therein. The manufacturer is not liable for damage caused by equipment used inappropriately or by incorrect handling.

1. General safety instructions



1.1 Electrical safety

- a) Make sure that the nominal voltage of the device and power source are compatible.
- b) The electrical supply system must be fitted with a residual-current circuit breaker with rated tripping current not higher than 30mA. Performance of the circuit breaker should be checked periodically.
- c) Periodically check the condition of the power cord. Replace the power cord if damaged. Replacing the power cord can only be performed by the manufacturer or by qualified personnel. Do not use the device if the power cord is damaged!
- d) In the event of damage to the device, to avoid any health and safety risks, repairs should be carried out only by qualified personnel.
- e) Do not pull the power cord. Keep the power cord away from heat sources and sharp edges to ensure its good condition.



1.2. Operation safety

- a) The device is not intended for use by persons (including children) with limited physical, sensory or mental abilities, or by inexperienced users, unless under supervision or with instructions given by an accountable party.
- b) Protect against moisture (also while stored)
- c) Do not use the device near flammable materials
- d) Never carry out any maintenance or repairs during operation
- e) For indoor use only. The device is not suitable for outdoor use.

2. Product description

The device is designed to generate steam. It may be used for frame disinfecting, wax melting, etc.



Components:

- 1-hose
- 2-cap
- 3-safety valve
- 4-water tank

2.1. Preparation for use

- 1- Attach the hose (1) to the water tank (4) by gripping the end of the hose and screwing it firmly onto the tank's steam outlet nozzle.
- 2- before filling the tank with water, make sure that the device is unplugged and cooled, and that there is no hot steam steam still in the hose (1)
- 3- place the device on a level surface and unscrew the tank's cap (3)
- 4- fill the water tank (4) to the required level - maximum capacity 4 litres
- 5- replace the tank cap (3).
- 6- plug the device in and the device is ready to work
- 7- unplug the generator after its work is done

2.2. Technical specifications

- power supply 230V/50Hz
- power output 2000W
- capacity 4L.

3. Storage

Clean and dry the unit thoroughly after use.
Store the device in a dry and frost-free room.

An additional technical check should be carried out periodically, and if any defects are found, please contact the manufacturer.

4. Cleaning and maintenance



IMPORTANT!

If you notice a build-up of limescale on the heater, purchase a suitable descaling agent and apply it to the device. Limescale deposits increase the boiling time of the water and can cause the heating element damage. After removing the deposits, boil the water a few times and empty the tank completely. Remove any residues of the descaling agent from the generator, as it may cause corrosion of the metal elements.

Before first use and after finishing work the equipment must be thoroughly cleaned and dried.

Wash the device with hot water with the addition of detergents (approved for use in the food industry).

While cleaning ensure the safety of all electrical components

Rinse thoroughly and dry before storing.

Store the device in a dry and frost-free room.

No parts of the device require any additional chemical conservation.

5. Waste disposal and environmental protection

The used product must be disposed in accordance with the local regulations. Return the device to a collection point from where it can be submitted for environmentally compatible recycling.

The consumer has the right to return used equipment directly to the manufacturer's distribution network, free of charge, while replacing it with a new unit as long as the used device is of the same kind and same application as the newly purchased device.

6. Warranty

The product purchased from the Lyson Company is covered by a manufacturer's warranty. The warranty period is 24 months from the date of purchase.

All purchased products come with receipts or VAT invoices.

Warranty details at:

www.lyson.com.pl